

ABOUT GPS SENSOR

1 GPS

2 Digital Alarms (Active High or Low)

1. Power In

9 – 36 Vdc power

2. Ground

Supply negative = Ground = Boat chassis

3. No Connect

4. No Connect

5. Digital Alarm 1

Normally Open or Closed

0-36 Vdc

24-12 AWG Wire

6. Digital Alarm 1 Ground

Supply negative = Ground = Boat chassis

7. Digital Alarm 2


Normally Open or Closed

0-36 Vdc

24-12 AWG Wire

8. Digital Alarm 2 Ground

Supply negative = Ground = Boat chassis



Potential Alarm Connections

Fire Detector
Door Open/Close
Motion Detector